AeroGraphics
The Original Aircraft Lettering Company

Piper PA-28 140-180 Cherokee Exterior Kit

NOTE: Modifications and changes to accomodate your specific aircraft will be made at NO EXTRA CHARGE.
Partial kits available upon request.

IF YOU HAVE ANY QUESTIONS PLEASE CALL!

Phone: 1-800-336-9633 www.aerographics.com Fax: 1-970-461-2065

EXT. PWR.
12 V.D.C.
MASTER OFF
WHEN
IN USE

CLOSE OPEN

BATTERY
SERVICE
INSIDE
COWL

CHECK
LATCHES

24 U.S. GAL

36 U.S. GAL

24 U.S. GAL

36 U.S. GAL

6 QTS

8 QTS

SECURE PRIOR
TO FLIGHT

SECURE PRIOR
TO FLIGHT

HYD FILL
INSIDE
COWL

FUEL SUMP
DRAIN

PULL TO
OPEN

HAND
HOLD

AERPGRAPHICS
800-366-9600

PIPER PA 28
CHEROKEE 140
EXTERIOR PLACARD KIT

LIFT DETECTOR

DO NOT PUSH

DO NOT PUSH

NO
STEP

DOOR RELEASE

NO
STEP

DOOR RELEASE

PITOT DRAIN

NO HOLD

STATIC VENT
KEEP CLEAN

STATIC VENT
KEEP CLEAN

NO HOLD

WARNING: FLAP STEP UNSAFE

EXTERNAL POWER
24 VOLTS D.C.
TURN MASTER SWITCH
AND ALL EQUIP. OFF
BEFORE INSERTING
OR REMOVING PLUG

EXTERNAL POWER
12 VOLTS D.C.
TURN MASTER SWITCH
AND ALL EQUIP. OFF
BEFORE INSERTING
OR REMOVING PLUG

TURN
LIMIT

E.L.T.
LOCATED BEHIND PANEL

OXY FILL
SEE POH

LEVEL POINT

LEVEL POINT

OIL FILL
CHECK POINT
INSIDE
COWL

BAGGAGE DOOR
SECURE PRIOR
TO FLIGHT

CAUTION
TOW LIMITS

FUEL DRAIN

FUEL DRAIN

CAUTION
TOW LIMITS

FUEL
100-130 AVIATION GRADE MIN.
CAPACITY 17 GAL.

FUEL
100-130 OCTANE MIN.
MAXIUM CAPACITY 38 GAL.
CAPACITY TO BOTTOM OF
FILLER NECK INDICATOR 31 GAL.

FUEL
100-130 OCTANE MIN.
MAXIUM CAPACITY 38 GAL.
CAPACITY TO BOTTOM OF
FILLER NECK INDICATOR 31 GAL.

SERVICE INSTRUCTIONS
MAIN TIRE PRESSURE 24 P.S.I.
TO FILL STRUT REMOVE AIR VALVE
FILL STRUT IN COMPRESSED POSITION
WITH HYDRAULIC FLUID
REPLACE VALVE
SEE OWNERS HANDBOOK FOR
INSTRUCTIONS ON STRUT
EXTENTION

SERVICE INSTRUCTIONS
MAIN TIRE PRESSURE 24 P.S.I.
TO FILL STRUT REMOVE AIR VALVE
FILL STRUT IN COMPRESSED POSITION
WITH HYDRAULIC FLUID
REPLACE VALVE
SEE OWNERS HANDBOOK FOR
INSTRUCTIONS ON STRUT
EXTENTION

SERVICE INSTRUCTIONS
NOSE TIRE PRESSURE 18 P.S.I.
TO FILL STRUT REMOVE AIR VALVE
FILL STRUT IN COMPRESSED POSITION
WITH HYDRAULIC FLUID
REPLACE VALVE
SEE OWNERS HANDBOOK FOR
INSTRUCTIONS ON STRUT
EXTENTION

SERVICE INSTRUCTIONS
PIPER STRUT SERIAL NO.
EXTEND STRUT, RELEASE AIR, REMOVE OIL
LEVEL PLUG. FILL UPRIGHT STRUT WITH
MIL-H-5606 HYDRAULIC OIL. COMPRESS
STRUT FULLY. REPLACE PLUG. INFLATE AND
MAINTAIN 2.00 INCHES VISIBLE STRUT
EXTENSION UNDER STATIC LOAD.

SERVICE INSTRUCTIONS
PIPER STRUT SERIAL NO.
EXTEND STRUT, RELEASE AIR, REMOVE OIL
LEVEL PLUG. FILL UPRIGHT STRUT WITH
MIL-H-5606 HYDRAULIC OIL. COMPRESS
STRUT FULLY. REPLACE PLUG. INFLATE AND
MAINTAIN 2.00 INCHES VISIBLE STRUT
EXTENSION UNDER STATIC LOAD.

SERVICE INSTRUCTIONS
PIPER STRUT SERIAL NO.
EXTEND STRUT, RELEASE AIR, REMOVE OIL
LEVEL PLUG. FILL UPRIGHT STRUT WITH
MIL-H-5606 HYDRAULIC OIL. COMPRESS
STRUT FULLY. REPLACE PLUG. INFLATE AND
MAINTAIN 2.00 INCHES VISIBLE STRUT
EXTENSION UNDER STATIC LOAD.

Phone: 1-800-336-9633 www.aerographics.com Fax: 1-970-461-2065