

## North American T-6 Texan Exterior Kit

PAGE 1 of 3

NOTE: Modifications and changes to accomodate your specific aircraft will be made at NO EXTRA CHARGE. Partial kits available upon request.

IF YOU HAVE ANY QUESTIONS PLEASE CALL!

Phone: 1-800-336-9633 Fax: 1-970-461-2065 www.aerographics.com

4221 W. EISE LOVELAND	GRAPHICS INHOWER BLVD. , CO 80538 ERIOR KIT	OIL Drain	EXTERNA HEAT	L 11 22 33
FUEL Straine	HYD FLUID R TANK		HAND HO GAS VALV	LD 44 55
VENT VAILERON CABLES	VENT VEN AILERON CABLES	T VENT AILERON CABLES	VENT AILERON CABLES	OLEO Aileron Cables
AILERON CABLES	AILERON Cables	AILERON CABLES	AILERON CABLES	AILERON Cables

REMOVE 5 BOLTS INSIDE

BEFORE REMOVING WING

REMOVE 5 BOLTS INSIDE BEFORE REMOVING WING

CAUTION DO NOT JACK HERE WITH TANK DOORS REMOVER

CAUTION DO NOT JACK HERE WITH TANK DOORS REMOVER

BATTERY HOIST

**EJECT** 

10.2 U.S. GAL.

CHUTE

CAUTION DISCONNECT ELECTRICAL WIRING AND BOMB CABLES BEFORE REMOVING WING

CAUTION DISCONNECT ELECTRICAL **WIRING AND BOMB CABLES** BEFORE REMOVING WING

Phone: 1-800-336-9633 www.aerographics.com Fax: 1-970-461-2065



## North American T-6 Texan Exterior Kit PAGE 2 of 3

NOTE: Modifications and changes to accomodate your specific aircraft will be made at <u>NO EXTRA CHARGE</u>. Partial kits available upon request.

IF YOU HAVE ANY QUESTIONS PLEASE CALL!

Phone: 1-800-336-9633 www.aerographics.com Fax: 1-970-461-2065

100 LB. BOMB LOADING INSTRUCTION.
PULL CHARGING CABLES ALL THE WAY
OUT AND HOLD. INSTALL BOMB IN NO. 2
POSITION. RELEASE CHARGING CABLE.
INSTALL REMAINING BOB IN NO. 4
POSITION.

20 & 30 LB. BOMB LOADING INSTRUCTION.
PULL CHARGING CABLE ALL THE WAY
OUT AND HOLD. INSTALL BOMB IN NO. 1
INSTALL REMAINING BOMBS IN FOLLOWING ODER 2.3.4.&5.

FIRE EXTINGISHER INSIDE

GROUND GROUND CAUTION PLUMB C.L. PLUMB C.L.

SERVICE THIS AIRPLANE
WITH 87 OCTANE FUEL.
IF NOT AVAILABLE, THE
NEXT HIGHER GRADE WILL
BE USED IN EMERGENCY.

SERVICE THIS AIRPLANE WITH 87 OCTANE FUEL. IF NOT AVAILABLE, THE NEXT HIGHER GRADE WILL BE USED IN EMERGENCY.

20 & 30 LB. BOMB LOADING INSTRUCTION.
PULL CHARGING CABLE ALL THE WAY
OUT AND HOLD. INSTALL BOMB IN NO. 1
INSTALL REMAINING BOMBS IN FOLLOWING ODER 2,3,4,&5.

STARTER
MOVE BRUSH LIFTING LUG
ON REAR OF STARTER TO
OFF POSTION FOR HAND
CRANKING

MOOR MOOR PUSH PUSH PUSH PUSH

TOW TOW HOIST OLEO OLEO JACK JACK CAUTION SERVICE SERVICE

CAUTION DO NOT LIFT

DO NOT LIFT

DO NOT LIFT

Phone: 1-800-336-9633 www.aerographics.com Fax: 1-970-461-2065



## North American T-6 Texan Exterior Kit PAGE 3 of 3

NOTE: Modifications and changes to accomodate your specific aircraft will be made at <u>NO EXTRA CHARGE</u>.

Partial kits available upon request.

IF YOU HAVE ANY QUESTIONS PLEASE CALL!

Phone: 1-800-336-9633 www.aerographics.com Fax: 1-970-461-2065

100 LB. BOMB LOADING INSTRUCTION.
PULL CHARGING CABLES ALL THE WAY
OUT AND HOLD. INSTALL BOMB IN NO. 2
POSITION. RELEASE CHARGING CABLE.
INSTALL REMAINING BOB IN NO. 4
POSITION.

20 & 30 LB. BOMB LOADING INSTRUCTION.
PULL CHARGING CABLE ALL THE WAY
OUT AND HOLD. INSTALL BOMB IN NO. 1
INSTALL REMAINING BOMBS IN FOLLOWING ODER 2.3.4.&5.

FIRE EXTINGISHER INSIDE

GROUND GROUND CAUTION PLUMB C.L. PLUMB C.L.

SERVICE THIS AIRPLANE
WITH 87 OCTANE FUEL.
IF NOT AVAILABLE, THE
NEXT HIGHER GRADE WILL
BE USED IN EMERGENCY.

SERVICE THIS AIRPLANE WITH 87 OCTANE FUEL. IF NOT AVAILABLE, THE NEXT HIGHER GRADE WILL BE USED IN EMERGENCY.

20 & 30 LB. BOMB LOADING INSTRUCTION.
PULL CHARGING CABLE ALL THE WAY
OUT AND HOLD. INSTALL BOMB IN NO. 1
INSTALL REMAINING BOMBS IN FOLLOWING ODER 2,3,4,&5.

STARTER
MOVE BRUSH LIFTING LUG
ON REAR OF STARTER TO
OFF POSTION FOR HAND
CRANKING

MOOR MOOR PUSH PUSH PUSH PUSH

TOW TOW HOIST OLEO OLEO
JACK JACK CAUTION SERVICE SERVICE

CAUTION DO NOT LIFT STEP

DO NOT LIFT DO NOT LIFT

Phone: 1-800-336-9633 www.aerographics.com Fax: 1-970-461-2065