

Mooney Exterior Kit PAGE 1 of 2

NOTE: Modifications and changes to accomodate your specific aircraft will be made at <u>NO EXTRA CHARGE</u>. Partial kits available upon request.

IF YOU HAVE ANY QUESTIONS PLEASE CALL!

Phone: 1-800-336-9633 www.aerographics.com Fax: 1-970-461-2065

NO STEP NO PUSH DO NOT PUSH NO STEP NO PUSH HOIST POINT NO STEP NO PUSH HOIST POINT TIRE PRESSURE 42 PSI HOIST POINT TIRE PRESSURE 42 PSI **FUEL DRAIN** TIRE PRESSURE 49 PSI NO HAND HOLD TIRE PRESSURE 30 PSI TIRE PRESSURE 30 PSI

PLEASE DO NOT SCRATCH PAINT WHILE FLIFTING **USE AVIATORS** OPERATE **OXYGEN ONLY** SEE PILOT'S OPERATING HANDBOOK FOR FILLING PRESSURES SUMP DRAIN HAND HOLD MANUALLY LEVEL POINT PITOT DRAIN HAND HOLD **GASCOLATOR DRAIN FUEL DRAIN** Š STATIC DRAIN **GROUND POINT** 8 **GROUND POINT FUEL DRAIN** Actuated STATIC VENT 28 VOLTS **KEEP CLEAR** ONLY GAS COLLATOR NO STEP **Electrically** STATIC AIR KEEP CLEAN NO STEP STATIC AIR KEEP CLEAN MAGNETIC AZIMUTH TRANSMITTER
LOCATED INSIDE THIS INSPECTION
COVER. USE ONLY NON-MAGNETIC
SCREWS FOR COVER INSTALLATION





Mooney Exterior Kit PAGE 2 of 2

NOTE: Modifications and changes to accomodate your specific aircraft will be made at <u>NO EXTRA CHARGE</u>. Partial kits available upon request.

IF YOU HAVE ANY QUESTIONS PLEASE CALL!

Phone: 1-800-336-9633 www.aerographics.com Fax: 1-970-461-2065



