

## Piaggio P180 Avante Exterior Kit PAGE 1 of 1

NOTE: Modifications and changes to accomodate your specific aircraft will be made at <u>NO EXTRA CHARGE</u>. Partial kits available upon request.

IF YOU HAVE ANY QUESTIONS PLEASE CALL!

Phone: 1-800-336-9633 www.aerographics.com Fax: 1-970-461-2065

NO STEP NO STEP M4X/MUM FUELING PRESSURE 60 PSIC NO DEFUELING ALLOWED **BAGGAGE** 400 LBS MAX. 181 KG **FUEL** JET A, JET A1, JET B PER ASTM D1655 **PRESSURE CLOSE** PFA-55MB OR MIL-1-27686 ADDITIVE MUST BE BLENDED ECS OIL UNDER BAGGAGE FLOOR REFUELING MIL-T-5624 GRADE JP4 MIL-T-83133 GRADE JPS **CLOSE** HYD. OIL FILLING PORT **GRAVITY DEFUELING** EXTERNAL PRESSURIZATION SEE AIRPLANE FLT. MANUAL FOR APPROVED FUELS QUANTITY OF ADDITIVE AND FUELING PROCEDURE OPEN SHOCK ABSORBER INFLATE WITH NITROGEN TO 120±10 PSIG FOR FILLING INSTRUCTION SEE MAINTENANCE MANUAL 28VDC 1200A PEAK FOR STARTING **ENGINE OIL ENGINE OIL OPEN** MIL-L-23699 MIL-L-23699 400A MAX CONT. FOR SERVICE INFLATE TIRE 64± 2 PSIG **ECS OIL** FILLING INSTRUCTION

1. OPEN OVERFILLING VALVE ON L.G. BAY

2. REMOVE H.U.G FROM FILLING PORT AND CONNECT HOSE
FROM HAND PUNP

3. PUMP OIL MILH-4-SGOS OR EQUIVALENT TO OVERFILMY
FROM OVERFILLING VALVE

1. OLL CAPACITY FROM LOW LEVEL TO MAX LEVEL 200 CC. STATIC MIL-L-23699 TANK CAPACITY 53 CC. SEE AIRPLANE FLT. MANUAL FOR APPROVED FUEL **DRAIN**  FCS DRAIN VALVE: OPEN
 FILL TO OVERFLOW FROM
 ECS DRAIN VALVE
 GS DRAIN VALVE: CLOSE PACITY FROM LOW LEVEL TO MAX LEVEL 200 CC.
//E HOSE AND PLUG FILLING PORT:
OVERFILLING VALVE INFLATE TIRE FUEL QUANTITY OF ADDITIVE AND SHOCK ABSORBER INFLATE WITH NITROGEN TO 915 ± 50 PSIG FOR FILLING INSTRUCTION SEE MAINTENANCE MANUAL HYD. OVERFILL VALVE